


3 for

Spare Part List



Model No. Y420302

Pos.	Art. No.	Description	Pos.	Art. No.	Description
1	Y420302-1	Retaining Ring	20	Y420302-20	Lower Handle
2	Y420302-2	Washer	21	Y420302-21	Upper Handle
3	Y420302-3	Wheel	22	Y420302-22	Bolt M6x35
4	Y420302-4	Side Plate Assy.	23	Y420302-23	Top Cover
5	Y420302-5	Washer	24	Y420302-24	Power Unit Assy
6	Y420302-6	Nut M16	25	Y420302-25	Spring
7	Y420302-7	Spring Washer	26	Y420302-26	Retaining Ring
8	Y420302-8	Bolt M12x20	27	Y420302-27	Block Linkage
9	Y420302-9	Rear Caster Assy.	28	Y420302-28	Bolt
10	Y420302-10	Shaft Arm	29	Y420302-29	Lifting Arm
11	Y420302-11	Retaining Ring	30	Y420302-30	Saddle
12	Y420302-12	Spring Washer	31	Y420302-31	Long Linkage
13	Y420302-13	Bolt	32	Y420302-32	Retaining Ring
14	Y420302-14	Spring Washer	33	Y420302-33	Pull Rod
15	Y420302-15	Spring Washer	34	Y420302-34	Washer
16	Y420302-16	Cover	35	Y420302-35	Nut M12
17	Y420302-17	Nut M16	36	Y420302-36	Torsion Spring
18	Y420302-18	Handle Socket			
19	Y420302-19	Boit	RK	Y420302-RK	Repair Kit