


TIRE TOOL



Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	SG-0775	Impact Wrench Tool	17	TF-404033	Lock Seat
2	TF-404041	Connector	18	TF-404034	Lock Hook
3	OR03805200	O-Ring (Ø38.5xØ2)	19	40317-13	Spring Pin (Ø3×12L)
4	TF-404036	Clamp Nut	20	TF-404021	Key
5	TF-404035	Adjustment Screw	21	TF-404028	Pushing Arm
6	0AS2035	Washer(4)	22	TF-404038	Screw (M14×30L)
7	0AXK2035	Needle Bearing(2)	23	TF-404030	Nipper
8	TF-404039	Screw	24	TF-404022	Roller(2)
9	TF-404023	Washer	25	TF-404032	Hold Arm(Right)
10	TF-404042	Adapter Tube	26	526125	Screw(6) (M6×16L)
11	TF-404026	Lock Pin	27	51534	Screw Nut(2)
12	TF-404043	Spring	28	TF-404031	Hold Arm(Left)
13	TF-404044	Steel Ball Cover	29	TF-404049	Side Handle
14	TF-404048	Retainer Ring	30	62048-11	Screw(2) (M5×25L)
15	TF-404040	Spindle	31	TF-404025	Screw (M6×8L)
16	TF-404020	Steel Ball(7) (6.5mm)			